

# MeridiClean™

## ALL PURPOSE CLEANER & DISINFECTANT

Cleans and disinfects in one easy step.



### WHY MERIDICLEAN:

#### EFFECTIVE AGAINST SARS-COV-2

\*See SARS-CoV-2 claim on page 2

#### 5 MINUTE CONTACT DISINFECTION OF COMMON ORGANISMS

#### BACTERICIDE, FUNGICIDE, VIRUCIDE - KILLS NOROVIRUS

#### NEUTRAL PH:

Won't stain or dull finish, non-corrosive to fixtures  
and equipment

#### DEODORIZES

### DIRECTIONS

See reverse side for pathogens this product is effective against.

Dilute with water according to product instructions. Apply solution with a mop,  
cloth, sponge, hand pump trigger sprayer or low pressure coarse sprayer. Allow to  
remain visibly wet for specified contact time, then remove excess liquid.

Read all directions and Safety Data Sheet (SDS) before using.

Directions and SDS are available for download at [pioneereclipse.com](http://pioneereclipse.com)

### TECHNICAL DATA

**Description** Cleaner/Disinfectant/Deodorant

**Appearance** Clear green

**Viscosity  
(Brookfield)** <10 centipoise  
@ 68°F (20°C)

**VOC** <0.01%  
40 CFR Part 59 Subpart C

**pH** 7-8  
ASTM E70-07

**% Actives** 8.7% (as supplied)

**Fragrance** Fresh citrus

**Shelf Life** 1 year  
ASTM D1791-93 (2008)

**Density** 8.3 lb/gal @ 68°F  
ASTM D1475-98 (2008) 1.0 kg/L @ 20°C

**US EPA  
Registration** 6836-366-41567

**DIN** 02518430

SURFACES



#### FLOOR COATING COMPATIBILITY

This disinfectant is safe to use  
on Pioneer Eclipse floor coatings  
when correctly diluted and  
used according to the product  
directions.

<b>Product Code</b>	625DC	625MPC
<b>Volume</b>	4 liters	4 liters
<b>Shipping Package</b>	4 x 4 liters	4 x 4 liters
<b>Pallet Quantity</b>	48	48

# MeridiClean™

## ALL PURPOSE CLEANER & DISINFECTANT



### SARS-CoV-2 Claim

\*Kills Human Coronavirus and is likely to kill SARS-CoV-2 (the virus that causes COVID-19).

When diluted at the rate of 16 ml per liter of water, this product exhibits effective 5 minute contact time disinfectant activity against the organisms: *Pseudomonas aeruginosa*, *Salmonella enterica*, *Staphylococcus aureus*, *Acinetobacter baumannii*, *Enterobacter aerogenes*, *Enterobacter cloacae* NDM 1 – Carbapenem Resistant [CRE], *Enterococcus faecalis* - Vancomycin resistant [VRE], *Escherichia coli*, *Escherichia coli* O157:H7, *Escherichia coli* – Extended Spectrum Beta Lactamase producing [ESBL E. Coli], *Escherichia coli* NDM-1 – Carbapenem Resistant [CRE], *Klebsiella pneumoniae*, *Klebsiella pneumoniae* – Extended Spectrum Beta Lactamase producing, *Klebsiella pneumoniae* NDM 1- Carbapenem Resistant [CRE], *Staphylococcus aureus* - Methicillin resistant (MRSA), and *Staphylococcus aureus* - Vancomycin resistant (VRSA), and meets AOAC efficacy standards for hospital disinfectants in 5 minutes.

**INSTRUCTIONS FOR CLEANING AND DECONTAMINATING AGAINST HIV-1 ON SURFACES AND OBJECTS SOILED WITH BLOOD OR BODILY FLUIDS:** This product is effective against [Human Immunodeficiency Virus] [HIV-1], [Hepatitis B Virus] [HBV] and [Hepatitis C Virus] [HCV] in the presence of organic soil [5% blood serum]

**PERSONAL PROTECTION:** When handling items soiled with blood or bodily fluids, wear disposable latex gloves, gowns, masks, and eye coverings.

**CLEANING PROCEDURE:** Thoroughly clean blood or bodily fluids from surfaces before applying MeridiClean All Purpose Cleaner & Disinfectant.

**CONTACT TIME:** To kill HIV-1, HBV and HCV apply MeridiClean All Purpose Cleaner & Disinfectant at 16 mL/L of water and allow surface to remain wet for 5 minutes.

**DISPOSAL OF INFECTIOUS MATERIAL:** Blood, body fluids, cleaning materials and clothing should be autoclaved and disposed of according to local regulations for infectious waste disposal. Any material used in the cleaning process that may contain feces/waste are to be disposed of immediately in accordance with local regulations for infectious materials disposal.

### CANINE PARVOVIRUS (CPV) ACTIVITY:

At 128 mL per L of water, MeridiClean is effective against Canine Parvovirus on hard, non-porous surfaces, with a 10 minute contact time.

This product is not to be used as a terminal sterilant / high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. [This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection].

Product Code	625DC	625MPC
Volume	4 liters	4 liters
Shipping Package	4 x 4 liters	4 x 4 liters
Pallet Quantity	48	48