

EnviroStar[™]

EXTRACTOR & PRE-SPRAY CLEANER



Concentrated cleaner for cold water extraction or spray-on application.

Read all directions and Safety Data Sheets (SDS) before using.

For synthetic carpet extraction:

- 1. Mix cleaner in a carpet extractor at a dilution of: 1:128 (1 US oz per gallon / 8 ml per 1 liter cold water).
- 2. Thoroughly clean with carpet extractor. Use defoamer in recovery tank if required.
- 3. Groom carpet with clean carpet rake or stiff synthetic broom and allow to dry.

As a pre-spray:

- 1. Thoroughly vacuum carpet and pre-treat spots.
- 2. Mix in a pump-up sprayer at a dilution of 1:8 (16 US oz per gallon / 125 ml per 1 liter of cold water).
- 3. Spray carpet completely. Agitate with a carpet rake, extractor brush, shampoo brush or bonnet.
- 4. Allow 10-15 minutes for cleaner to completely loosen soils. Do not allow to dry out.
- 5. Thoroughly clean with carpet extractor and water. Use defoamer in recovery tank if required.
- 6. OPTIONAL: Thoroughly rinse carpet with extractor and extraction rinse according to label directions.
- 7. Groom carpet and allow to dry.

PRODUCT INFO

Product Code 831MPE

1.06 US gallons Volume (3,8 liters)

4 x 1.06 gallons

Shipping Package (4 x 3,8 liters)

Pallet Quantity 48

SURFACES





CARPET

UPHOLSTERY

TECHNICAL DATA

Description Carpet extraction & pre-spray cleaner

Appearance Clear, light amber liquid

pH 9.5 (as supplied)

Viscosity (Brookfield) <10 centipoise

0.78% (as supplied) VOC 0.09% (1:8) 40 CFR Part 59 Subpart D 0.01% (1:128)

Fragrance None Added

Shelf Life 2 years

Density 8.9 lb/gal @ 68°F ASTM D1475-13 1.07 kg/L @ 20°C

Flash Point >200°F (93°C)

Freeze/Thaw Passes 3 cycles

Container 1.06 US gallons



